



# LUXURON

## OPERATING INSTRUCTIONS




# OPERATING THE BLIND


## LUXURON OPERATING INSTRUCTIONS



Press the up side of the switch to make the blind rise and simultaneously tilt forward. Slats will tilt while rising until reaching the tilt limit.



Press the down side of the switch to make the blind lower and simultaneously tilt backward. Slats will tilt while lowering until reaching the tilt limit.



Move the switch to the center position to stop the lifting or tilting at any time.